Copyright © Nokia Mobile Phones

Contents

Disassembly Instructions 6–1–2

Copyright © Nokia Mobile Phones

Disassembly Instructions



S0001005

Remove the battery.



S0001006

Remove the SIM card.

Now remove two back cover screws and remove the back cover by lifting it away.


S0001008


S0001009

Then remove six chassis screws.

Copyright © Nokia Mobile Phones



S0001010

Remove the chassis by lifting.

Now the SIM card holder can be lifted off.



S0001011



S0001012

Turn around the chassis and open the display module a little.

Open the display module connector by pressing both sides of connector and slide off the display module cable.



S0001013

Copyright © Nokia Mobile Phones

NHE–1 and NHK–1:
Turn chassis again and remove two module screws.

NHE–4, NHK–4, NHB–2 and NHB–3: Remove three/four module screws.



S0001014



S0001015

Remove the plastic shield and throw it away (it is disposable).

Now you can separate the system module from the bottom shield by lifting it away.